

## MAGNETIC STROBE SMALL BEACON

	PART.NO.	FLASH PATTERN	COLOUR	CURRENT DRAW @ 12V	OPERATING VOLTAGE	JOULES	FLASHTUBE	DIMENSIONS
	S1211ABM	Single	Amber	0.25 Amps	12-80 VDC	1.5 J/s (1.9 W/s)	L4613D	110mm (H)
	S1221ABM	Double		0.5 Amps	12-80 VDC	1.4 J/s (1.7 W/s)	L4614B	129mm (D)
	S1231ABM	Triple		0.5 Amps	12-80 VDC	1.5 J/s (1.9 W/s)	L4614B	
	S1211BBM	Single	Blue	0.25 Amps	12-80 VDC	1.5 J/s (1.9 W/s)	L4613D	110mm (H)
	S1221BBM	Double		0.5 Amps	12-80 VDC	1.4 J/s (1.7 W/s)	L4614B	129mm (D)
	S1231BBM	Triple		0.5 Amps	12-80 VDC	1.5 J/s (1.9 W/s)	L4614B	
	S1211CBM	Single	Clear	0.25 Amps	12-80 VDC	1.5 J/s (1.9 W/s)	L4613D	110mm (H)
	S1221CBM	Double		0.5 Amps	12-80 VDC	1.4 J/s (1.7 W/s)	L4614B	129mm (D)
	S1231CBM	Triple		0.5 Amps	12-80 VDC	1.5 J/s (1.9 W/s)	L4614B	
	S1211GBM	Single	Green	0.25 Amps	12-80 VDC	1.5 J/s (1.9 W/s)	L4613D	110mm (H)
	S1221GBM	Double		0.5 Amps	12-80 VDC	1.4 J/s (1.7 W/s)	L4614B	129mm (D)
	S1231GBM	Triple		0.5 Amps	12-80 VDC	1.5 J/s (1.9 W/s)	L4614B	
	S1211RBM	Single	Red	0.25 Amps	12-80 VDC	1.5 J/s (1.9 W/s)	L4613D	110mm (H)
	S1221RBM	Double		0.5 Amps	12-80 VDC	1.4 J/s (1.7 W/s)	L4614B	129mm (D)
	S1231RBM	Triple		0.5 Amps	12-80 VDC	1.5 J/s (1.9 W/s)	L4614B	

- PC Board is epoxy potted to extend the lifespan of the beacon.
- Also available as a permanent mount.
- To ensure that moisture does not affect the operation of the beacon, always check that the O-ring is in the correct position.

## 1000 SERIES REPLACEMENT PARTS

<b>BRANCH GUARD</b>	<b>MAGNETIC KIT</b>	<b>POLE MOUNT</b>	<b>AMBER LENS</b>	<b>BLUE LENS</b>	<b>CLEAR LENS</b>	<b>GREEN LENS</b>	<b>RED LENS</b>
1200BG	1200M-KIT	1200PM	1200AL	1200BL	1200CL	1200GL	1200RL

## TECHNICAL DRAWING

