




# BOXER 700


Cuts Cardboard and Packaging safely, swiftly and efficiently

Please act responsibly when disposing of blades

Please handle all knives with care



For maximum efficiency it is important to read and adhere to the following guidelines



Puncture box with hook

Start with Boxer horizontal to material. Puncture with hook blade.



Vari-Guard fully retracted

Push down until front face of knife is in full contact against the box. At this point the Vari-Guard will be fully retracted, exposing straight blade. Transfer all cutting force onto the straight blade.



Vari-Guard back to safe position

Move knife along cutting line. As knife is removed from material, Vari-Guard will spring back into position, protecting user from any blade surface.

## STRAPPING

Cut conventionally on a diagonal across the strapping with the straight blade not the hook blade

## SHRINK WRAP

Cut at a side angle if tightly shrink wrapped to allow straight blade edge to maintain contact with the material

## BLADE CHANGE

1. Turn Button counter-clockwise until it pops up.
2. Swing open top section.
3. Reverse blades or replace with blades from storage pocket.
4. Swing shut.
5. Push button in and turn clockwise.



PLEASE PHOTOCOPY AND ISSUE TO ALL OPERATORS



Vision Safe  
10 Gill Lane  
MUNDARING WA 6073  
Tel: 08 9295 0624 Fax: 08 9295 0628  
E-mail: [sales@visionsafe.com.au](mailto:sales@visionsafe.com.au)  
Website: [www.visionsafe.com.au](http://www.visionsafe.com.au)

